Airis-C (Ceiling-mounted) Diagnostics Information



Press the OK button (large sensor button) or the remote button once to check diagnostics

Fault Code	Indication	Diagnosis
0	No Response	Check the batteries and test again
1	1 blue flash	Problem with the wireless connection between the sensor and PCU
2	2 blue flashes	Problem with the PCU
3	3 blue flashes	PCU overheated
4	1 yellow flash	Problem with a sensing device in the sensor unit
5	2 yellow flashes	Problem with the sensor
6	3 yellow flashes	Problem with the position of the sensor unit (the position of the sensor has changed from its position at the time of installation) - See section 3 of the installation manual
7	3 red flashes	Problem with the mounting bracket

Note: Please note the fault code before contacting us, this will enable us to assist you more effectively.

Unicook Ltd
Tel: +44 (0) 208 798 3462
Email: support@unicook.co.uk